

MARCA	CODIGO	NUM.PARTE	CODIGO ORIGINAL
HP	CC-015	45	51645A
HP	CC-016-TRI	17	C6625A
HP	CC-017-TRI	78	C6578A
HP	CC-031	15	C6615A
HP	CC-031-TRI	23	C1823
HP	CC-059	56	C6656
HP	CC-059-TRI	57	C6657
HP	CC-060	27	C8727
HP	CC-060-TRI	28	C8728
HP	CC-062	21	C9351
HP	CC-062-TXL	22	C9352
HP	CC-060-XL	60	CC641
HP	CC-060-TXL	60	CC644
HP	CC-063	92	C9362
HP	CC-063-TRI	93	C9361
HP	CC-064	94	C8765
HP	CC-064-TRI	95	C8766
HP	CC-065	96	C8767
HP	CC-065-TRI	97	C9363
HP	CC-066	98	C9364WL
HP	CC-067	74	CB336
HP	CC-067-TRI	75	CB338
HP	CC-069	901	CC654
HP	CC-069-TRI	901 C	CC656
HP	CC-563-XL	122	CH563
HP	CC-564-XL	122	CH564
HP	CC-662XL	662	CZ105AL
HP	CC-662-TXL	662	CZ106AL
HP	CC-664XL	664	F6V31AL
HP	CC-664TXL	664	F6V30AL
HP	CC-T664	T664	T664120-AL
HP	CC-T664-C	T665	T664220-AL
HP	CC-T664-Y	T666	T664320-AL
HP	CC-T664-M	T667	T664420-AL
EPSON	CR-052	63	T063120
EPSON	CR-052-CY	63	T063220
EPSON	CR-052-M	63	T063320
EPSON	CR-052Y	63	T063420
EPSON	CR-061	73	T073120
EPSON	CR-061-C	73	T073220
EPSON	CR-061-M	73	T073320
EPSON	CR-061-Y	73	T073420
EPSON	CR-070	132	T132120
EPSON	CR-071	133	T133120
EPSON	CR-071-C	133	T133220
EPSON	CR-071-M	133	T133320
EPSON	CR-071-Y	133	T133420
EPSON	CR-072	133	T133520
EPSON	CR-073	197	T197120
EPSON	CR-073-C	196	T196220
EPSON	CR-073-M	196	T196320
EPSON	CR-073-Y	196	T196420